





## NOTES:

- PURPSE IS TO CONVERT CONCENTRATED RUNOFF TO SHEET FLOW AND RELEASE IT ONTO UNDISTURBED AREAS WITH EXISTING VEGETATION, FOR THE PURPOSE OF INCREASING INFILTRATION AND DECREASING RUNOFF VOLUME.
- THE SLOPE LEADING TO THE SPREADER SHOULD BE LESS THAN 1% FOR AT LEAST 7M IMMEDIATLEY UPSTREAM IN ORDER TO HAVE SLOW VELOCITIES IN THE SPREADER.
- CONSTRUCT ONLY ON NATURAL SOIL, NOT ON FILL MATERIALS.
- ONLY MEANT FOR SMALL VOLUMES.
- ANY DAMAGE TO THE SPREADER SHALL BE IMMEDIATELY REPAIRED.
- THE DOWNSLOPE AREA SHALL BE CHECKED FOR SIGNS OF EROSION AND TO VERIFY THAT THE SPREADER IS NOT CREATING A POINT DISCHARGE. ANY ERODED AREAS SHALL BE IMMEDIATELY STABILIZED.

TEMPORARY LEVEL SPREADER BAR



2002 05 31