






BACK OF STAGE



FRONT OF STAGE




MAIN FLOOR SEATING




LX - CATWALK

LX Fixture Legend:

| Symbol | Meaning |
|--------|---------------|
| W | Warm (R-02) |
| C | Cool (R-63) |
| OW | Open White |
| R | Red (R-26) |
| B | Blue (R-80) |
| O | Orange (R-23) |
| T | Tip |
| OH | Overhead |
| CYC | Cyclorama |
| (#s) | Dimmer Number |



| Front Area Wash: | |
|-------------------------|--------|
| Coverage Area | Symbol |
| Down Stage Warm / Cools | 1 |
| Mid Stage Warm / Cools | 2 |
| Up Stage Warm / Cools | 3 |



| Color Area Wash: | |
|--------------------------------|---------------|
| Coverage Area | Symbol |
| Down Stage Colors & Open White | 1 |
| Up Stage Colors & Open White | 2 |