



NOTES:

1. PURPOSE IS TO SHORTEN SLOPE LENGTH, THEREBY REDUCING VELOCITY OF RUNOFF WATER AND TRAPPING ERODED SOIL.
2. ROLLS SHALL BE ALIGNED PARALLEL TO ELEVATION CONTOURS WITHIN A TRENCH HALF DIAMETER OF THE ROLL, NO GAPS SHOULD EXIST BETWEEN THE SOIL AND WATTLE.
3. PLACE HYDROSEED, MULCH OR STRAW ON SLOPE FOR ADDITIONAL EROSION CONTROL.
4. WHEN INSTALLING RUNNING LENGTHS OF WATTLES, BUTT THE SECOND WATTLE TIGHTLY AGAINST THE FIRST. DO NOT OVERLAP THE ENDS.
5. STAKE WATTLES 15cm FROM WATTLE ENDS, WITH STAKE ANGLED TOWARD THE ADJACENT WATTLE. ALSO STAKE ON 1.2m CENTERS. LEAVE 3-5cm OF STAKE EXPOSED ABOVE THE WATTLE.
6. IF THE GROUND IS HARD, A METAL ROD CAN BE USED TO "PRE-DRILL" A HOLE INTO THE SOIL FOR THE WOODEN STAKE.
7. REMOVE SEDIMENT DEPOSITED UPSLOPE OF THE WATTLE ONCE IT REACHES  $\frac{1}{3}$  OF THE WATTLE'S HEIGHT ABOVE THE GROUND SURFACE.

FIBER ROLLS / WATTLES



DRAWN: 2002 05 31

REVISED: 2010 07 26

APPROVED BY:

ES - EC - 13